


# Model No.DBN501 Cordless Brad Nailer



# Model No.DBN501 Cordless Brad Nailer

Item No.	Parts No.	Description	Interchangability	Q'ty	New/Old	Note1	Note2
001	266130-9	Binding head tapping screw 3X16		11			
002	1831D7-6	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	252103-8	Hex. lock nut M5-8		1			
002		INC. 22					
003	911248-8	Pan head screw M5X28 WR		1			
004	650060-8	Switch C3JR-5BM-PAND-2		1			
005	232884-0	Compression spring 7		1			
006	4130V7-5	Trigger		1	*		
006-1	1413L6-2	TRIGGER COMPLETE	O	1			
007	632V61-0	Switch unit		1			
008	232889-0	Leaf spring		1	*		
008-1	232889-0	Leaf spring	O	1			
009	654908-6	Terminal		1			
010	232876-9	Compression spring 7		2			
011	620P12-9	Controller		1			
012	652069-6	Flat head screw M3X6		3			
013	266490-9	Pan head tapping screw 2X6		3			
014	4130V8-3	LED holder		1			
015	620P87-8	LED circuit		1			
016	629A28-1	Stator		1			
017	210231-5	Ball bearing 625ZZ		1			
018	519865-4	Rotor assembly		1			
018		INC. 17,19					
019	210005-4	Ball bearing 608DDW		1			
020	266007-8	Binding head tapping screw 3X10		2			
021	620P99-1	Switch circuit complete		1			
022	1831D7-6	Housing set		1			
C10	263005-3	Rubber pin 6		2			
C20	252126-6	Hex. lock nut M4-7		2			
C30	252103-8	Hex. lock nut M5-8		1			
022		INC. 2					
023	122G77-8	Gear assembly		1			
024	227B71-6	Spur gear 14		4			
025	141Y39-5	Carrier complete		1			
026	210168-6	Ball bearing 6805DDW		1			
027	265995-6	Binding head tapping screw 4X18		2	*		
027-1	265E16-4	Tapping screw 4X18	<	2			
028	141Y44-2	Inner housing complete		1			
029	911007-0	Pan head screw M3X8		1			
030	620P94-1	Sensor circuit		1			
031	265995-6	Binding head tapping screw 4X18		4	*		
031-1	265E16-4	Tapping screw 4X18	<	4			
032	961006-2	Retaining ring (EXT) S-10		1			

033	347C87-2	Flat washer 10		1		
034	162D44-3	Holder complete		1		
035	232885-8	Compression spring 4		1		
036	347C81-4	Lifter plate		1		
037	256173-9	Pin 3.5		6		
038	327E03-2	Lifter		1		
039	327E09-0	Lifter shaft		1		
040	211391-6	Ball bearing 6900LLU		1		
041	4130V1-7	Lifter cap		1		
042	8148K6-5	Serial No. label DBN501		1		
043	8148K4-9	Name plate DBN501		1		
044	922232-8	Hex. socket head bolt M5X20		4		
045	327D23-0	Valve cap		1		
046	213007-9	O-ring 8		1		
047	243138-0	Valve core		1		
048	312H24-5	Top cap		1		
049	213A78-2	X-ring 23		1		
050	4130T8-9	Slide ring		2		
051	137238-5	Driver assembly		1	*	
051-1	137238-5	Driver assembly	O	1		
052	259092-8	Spiral retaining ring (EXT) 36		1		
053	422B82-8	Seal ring		1		
054	141Y40-0	Chamber complete		1		
055	213479-8	O-ring 33		2	*	
055-1	213A95-2	O-RING 33	<	2		
056	327D99-7	Cylinder		1		
057	422B80-2	Front cushion		1		
058	266007-8	Binding head tapping screw 3X10		3		
059	4130U1-0	Adjuster cover		1		
060	141V44-4	Switch plate complete		1		
061	232883-2	Leaf spring		1		
062	232882-4	Compression spring 9		1		
063	141Y46-8	Adjuster complete		1	*	
063-1	141Y46-8	Adjuster complete	O	1		
064	213021-5	O-ring 5		1		
065	961017-7	Stop ring (EXT) E-3		1		
066	347C76-7	Contact arm		1	*	
066-1	347C76-7	Contact arm		1		
067	422B81-0	Nose adapter		1		
068	951066-2	Spring pin 3-18		2		
069	313569-8	Driver guide		1		
070	4130T7-1	Latch cover		1		
071	162D43-5	Latch		1		
072	313568-0	Under driver guide		1		
073	265911-8	Hex. socket head bolt M4X8		2		
074	922228-9	Hex. socket head bolt M5X18 WR		2		
075	922117-8	Hex. socket head bolt M4X12		1		
076	347E02-8	Nail plate		1		
077	141Y42-6	Magazine complete		1		
C10	8082A9-3	Caution label		1		
078	313591-5	Stopper		1		

079	233018-8	Compression spring 3		1		
080	347C74-1	Pusher		1		
081	459313-0	Sleeve		2		
082	256877-3	Pin 3		1		
083	413329-9	Lever		1		
084	233117-6	Compression spring 6		1		
085	232881-6	Compression spring 6		2		
086	262054-7	Urethane ring 3		1		
087	141Y43-4	Slide door complete		1		
A01	251314-2	Truss head screw M4X12		1		
A02	346317-0	Hook		1		
A03	422B81-0	Nose adapter		2		

Please state Parts No. when your order.

Print Date 01/26/2026